# SERVICE&OPERATINGMANUAL

**ORIGINAL INSTRUCTIONS** 

E3

## 3" Elima-Matic Bolted Metal


with Metal Center Section

### E3 Metal Pumps

Stainless Steel

# 







## **Safety Information**

### **A** IMPORTANT



Read the safety warnings and instructions in this manual before pump installation and start-up. Failure to comply with the recommendations stated in this manual could damage the pump and void factory warranty.



When the pump is used for materials that tend to settle out or solidify, the pump should be flushed after each use to prevent damage. In freezing temperatures the pump should be completely drained between uses.

### **A** CAUTION



Before pump operation, inspect all fasteners for loosening caused by gasket creep. Retighten loose fasteners to prevent leakage. Follow recommended torques stated in this manual.



Plastic pumps and plastic components are not UV stabilized. Ultraviolet radiation can damage these parts and negatively affect material properties. Do not expose to UV light for extended periods of time.



#### **WARNING**

Pump not designed, tested or certified to be powered by compressed natural gas. Powering the pump with natural gas will void the warranty.



#### WARNING

The use of non-OEM replacement parts will void (or negate) agency certifications, including CE, ATEX, CSA, 3A and EC1935 compliance (Food Contact Materials). Warren Rupp, Inc. cannot ensure nor warrant non-OEM parts to meet the stringent requirements of the certifying agencies.

### WARNING



When used for toxic or aggressive fluids, the pump should always be flushed clean prior to disassembly.



Before maintenance or repair, shut off the compressed air line, bleed the pressure, and disconnect the air line from the pump. Be certain that approved eye protection and protective clothing are worn at all times. Failure to follow these recommendations may result in serious injury or death.



Airborne particles and loud noise hazards. Wear eye and ear protection.



In the event of diaphragm rupture, pumped material may enter the air end of the pump, and be discharged into the atmosphere. If pumping a product that is hazardous or toxic, the air exhaust must be piped to an appropriate area for safe containment.



Take action to prevent static sparking. Fire or explosion can result, especially when handling flammable liquids. The pump, piping, valves, containers and other miscellaneous equipment must be properly grounded.



This pump is pressurized internally with air pressure during operation. Make certain that all fasteners and piping connections are in good condition and are reinstalled properly during reassembly.



Use safe practices when lifting

## **ATEX Pumps - Conditions For Safe Use**

- 1. Ambient temperature range is as specified in tables 1 & 2 on the next page
- 2. ATEX compliant pumps are suitable for use in explosive atmospheres when the equipment is properly grounded in accordance with local electrical codes
- 3. Conductive Polypropylene, conductive Acetal or conductive PVDF pumps are not to be installed in applications where the pumps may be subjected to oil, greases and hydraulic liquids.
- 4. When operating pumps equipped with non-conductive diaphragms that exceed the maximum permissible projected area, as defined in EN ISO 80079-36: 2016 section 6.7.5 table 8, the following protection methods must be applied
  - Equipment is always used to transfer electrically conductive fluids or
  - Explosive environment is prevented from entering the internal portions of the pump, i.e. dry running.



## **Temperature Tables**

**Table 1. Category 2 ATEX Rated Pumps** 

Ambient Temperature	Process Temperature	Temperature	Maximum Surface
Range [°C]	Range [°C]	Class	Temperature [°C]
	-40°C to +80°C	T5	T100°C
	-40°C to +108°C	T4	T135°C
-20°C to +60°C	-40°C to + 160°C	Т3	
	-40°C to +177°C	(225°C) T2	T200°C

Table 2. Category M2 ATEX Rated Pumps for Mining

Ambient Temperature	Process Temperature
Range [°C]	Range [°C]
-20°C to +60°C	-40°C to +150°C

<u>Note:</u> The ambient temperature range and the process temperature range should not exceed the operating temperature range of the applied plastic parts as listed in the manuals of the pumps.

## **Table of Contents**

## SECTION 1: PUMP SPECIFICATIONS......1

- Nomenclature
- Performance
- Materials
- Dimensional Drawings

### **SECTION 2: INSTALLATION & OPERATION .10**

- Principle of Pump Operation
- Typical Installation Guide
- Troubleshooting

### SECTION 3: EXPLODED VIEW......13


- Composite Drawings
- Parts List
- Composite Drawings
- Parts List
- Materials Code

### **SECTION 4: WARRANTY & CERTIFICATES..18**

- Warranty
- EU Declaration of Conformity Machinery Directive
- EU Declaration of Conformity ATEX Directive

## **Explanation of Pump Nomenclature**

Your Serial #: (fill in from pump nameplate)



Model	Pump Size	Wetted Parts	Non-Wetted Parts	Diaphragm Material
E Elima-Matic	<b>6</b> 1/4"	<b>A</b> Aluminum	<b>A</b> Aluminum	1 Neoprene
<b>U</b> Ultra-Matic	<b>8</b> 3/8"	C Cast Iron	S Stainless Steel	2 Nitrile (Nitrile)
<b>V</b> V-Series	<b>5</b> 1/2"	S Stainless Steel	P Polypropylene	3 FKM (Fluorocarbon)
	7 3/4"	<b>H</b> Alloy C	<b>G</b> Groundable Acetal	4 EPDM
	<b>1</b> 1"	P Polypropylene	Z PTFE-coated Aluminum	5 PTFE
	<b>4</b> 1-1/4" or 1-1/2"	<b>K</b> Kynar	J Nickel-plated Aluminum	6 Santoprene XL
	<b>2</b> 2"	<b>G</b> Groundable Acetal	C Cast Iron	7 Hytrel
	<b>3</b> 3"	B Aluminum (screen mount)	Q Epoxy-Coated Aluminum	Y FDA Santoprene

Diaphragm	Series
R Rugged	

**D** Dome X Thermo-Matic

T Tef-Matic (2-piece) B Versa-Tuff (1-piece)

F FUSION (one-piece

integrated plate)

1 Neoprene 2 Nitrile 3 (FKM) Fluorocarbon

4 EPDM

5 PTFE 6 Santoprene XL 7 Hytrel

8 Polyurethane A Acetal

S Stainless Steel Y FDA Santoprene

#### Valve Ball Material Valve Seat/Valve Seat O-Ring Material

**Construction Design** 

9 Bolted

Α

C

0 Clamped

**Design Level** 

1 Neoprene 2 Nitrile

3 (FKM) Fluorocarbon

4 EPDM **5** PTFE 6 Santoprene XL

7 Hytrel 8 Polyurethane A Aluminum w/ PTFE O-Rings

Stainless Steel w/ PTFE O-Rings C Carbon Steel w/ PTFE O-Rings H Alloy C w/ PTFE O-Rings

T PTFE Encapsulated Silicone O-Rings

Y FDA Santoprene

**Miscellaneous Options B** BSP Tapered Thread

**CP** Center Port **ATEX** ATEX Compliant

FP Food Processing

**SP** Sanitary Pump **HP** High Pressure

**OE** Original Elima-Matic

F Flap Valve

**HD** Horizontal Discharge

3A 3-A Certified **UL** UL Listed **OB** Oil Bottle

More than one option may be specified for a particular pump model.



Model E3 Bolted Metal • 4

## **Materials**

Material Profile:		Operating Temperatures:	
CAUTION! Operating temperature limitations are as follows:	Max.	Min.	
Conductive Acetal: Tough, impact resistant, ductile. Good abrasion resistance and low friction surface. Generally inert, with good chemical resistance except for strong acids and oxidizing agents.	190°F 88°C	-20°F -29°C	
<b>EPDM:</b> Shows very good water and chemical resistance. Has poor resistance to oils and solvents, but is fair in ketones and alcohols.	280°F 138°C	-40°F -40°C	
<b>FKM:</b> (Fluorocarbon) Shows good resistance to a wide range of oils and sovents; especially all aliphatic, aromatic and halogenated hydrocarbons, acids, animal and vegetable oils. Hot water or hot aqueous solutions (over 70°F) will attack FKM.	350°F 177°C	-40°F -40°C	
Hytrel®: Good on acids, bases, amines and glycols at room temperatures only.	220°F 104°C	-20°F -29°C	
Neoprene: All purpose. Resistance to vegetable oils. Generally not affected by moderate chemicals, fats, greases and many oils and solvents. Generally attacked by strong oxidizing acids, ketones, esters and nitro hydrocarbons and chlorinated aromatic hydrocarbons.	200°F 93°C	-10°F -23°C	
<b>Nitrile:</b> General purpose, oil-resistant. Shows good solvent, oil, water and hydraulic fluid resistance. Should not be used with highly polar solvents like acetone and MEK, ozone, chlorinated hydrocarbons and nitro hydrocarbons.	190°F 88°C	-10°F -23°C	
Nylon: 6/6 High strength and toughness over a wide temperature range. Moderate to good resistance to fuels, oils and chemicals.	180°F 82°C	32°F 0°C	

<b>Polypropylene:</b> A thermoplastic polymer. Moderate tensile and flex strength. Resists stong acids and alkali. Attacked by chlorine, fuming nitric acid and other strong oxidizing agents.	180°F 82°C	32°F 0°C
<b>PVDF:</b> (Polyvinylidene Fluoride) A durable fluoroplastic with excellent chemical resistance. Excellent for UV applications. High tensile strength and impact resistance.	250°F 121°C	0°F -18°C
Santoprene®: Injection molded thermoplastic elastomer with no fabric layer. Long mechanical flex life. Excellent abrasion resistance.	275°F 135°C	-40°F -40°C
<b>UHMW PE:</b> A thermoplastic that is highly resistant to a broad range of chemicals. Exhibits outstanding abrasion and impact resistance, along with environmental stress-cracking resistance.	180°F 82°C	-35°F -37°C
<b>Urethane:</b> Shows good resistance to abrasives. Has poor resistance to most solvents and oils.	150°F 66°C	32°F 0°C
Virgin PTFE: (PFA/TFE) Chemically inert, virtually impervious. Very few chemicals are known to chemically react with PTFE; molten alkali metals, turbulent liquid or gaseous fluorine and a few fluoro-chemicals such as chlorine trifluoride or oxygen difluoride which readily liberate free fluorine at elevated temperatures.	220°F 104°C	-35°F -37°C

Maximum and Minimum Temperatures are the limits for which these materials can be operated. Temperatures coupled with pressure affect the longevity of diaphragm pump components. Maximum life should not be expected at the extreme limits of the temperature ranges.

#### **Metals:**

Alloy C: Equal to ASTM494 CW-12M-1 specification for nickel and nickel alloy.

**Stainless Steel:** Equal to or exceeding ASTM specification A743 CF-8M for corrosion resistant iron chromium, iron chromium nickel and nickel based alloy castings for general applications. Commonly referred to as 316 Stainless Steel in the pump industry.


For specific applications, always consult the Chemical Resistance Chart.

**Note:** This document is a high level guide. Please be aware that not all model and or material combinations are possible for all sizes. Please consult factory or your distributor for specific details.

## **Performance**

#### E3 - 3" Bolted Stainless Pump – Metal Center ELASTOMERIC AND TPE FITTED - RUGGED

El. B.O.
Flow Rate
Adjustable to 0-273 gpm (1,033 lpm)
Port Size
Suction 3" ANSI 150 lbs Class (DIN80)
Discharge 3" ANSI 150 lbs Class (DIN80)
<b>Air Inlet</b>
3/4"NPT (Stainless Steel Centers ONLY)
Air Exhaust
Suction Lift
Dry
Wet31' (9.4 m)
Max Solid Size (Diameter)
Max Noise Level
Shipping Weights
Stainless 245 lbs (111.1 kg)
** Stainless Center add 50 lbs. (22.7 kg)




NOTE: Performance based on the following: elastomeric fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.

#### E3 - 3" Bolted Stainless Pump – Metal Center ELASTOMERIC AND TPE FITTED - DOMED

Flow Rate
Adjustable to 0-252 gpm (954 lpm)
Port Size
Suction 3" ANSI 150 lbs Class (DIN80)
Discharge 3" ANSI 150 lbs Class (DIN80)
<b>Air Inlet</b>
3/4"NPT (Stainless Steel Centers ONLY)
Air Exhaust
Suction Lift
Dry
Wet32' (9.8 m)
Max Solid Size (Diameter)
Max Noise Level
Shipping Weights
Stainless 245 lbs (111.1 kg)

\*\* Stainless Center add . . . . . . . . . 50 lbs. (22.7 kg)




NOTE: Performance based on the following: elastomeric fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.

## E3 - 3" Bolted Stainless Pump – Metal Center PTFE FITTED

Stainless. . . . . . . . . . . . . . . . . 245 lbs (111.1 kg)

\*\* Stainless Center add . . . . . . . . . 50 lbs. (22.7 kg)




NOTE: Performance based on the following: PTFE fitted pump, flooded suction, water at ambient conditions. The use of other materials and varying hydraulic conditions may result in deviations in excess of 5%.





## **Dimensional Drawings**

### E3 Bolted Metal

Dimensions in inches (metric dimensions in brackets). Dimensional Tolerance .125" (3mm).









## **Dimensional Drawings**

### E3 Bolted Metal

### **Dimensionally Interchangeable with Versamatic Clamped Pumps**

Dimensions in inches (metric dimensions in brackets). Dimensional Tolerance .125" (3mm).






Model E3 Bolted Metal • 8

## **Dimensional Drawings**

## E3 Bolted Metal


## **Dimensionally Interchangeable with Wilden Clamped Pumps**

Dimensions in inches (metric dimensions in brackets). Dimensional Tolerance .125" (3mm).



[367.43]

## **Principle of Pump Operation**



Air-Operated Double Diaphragm (AODD) pumps are powered by compressed air or nitrogen.


The main directional (air) control valve distributes compressed air to an air chamber, exerting uniform pressure over the inner surface of the diaphragm . At the same time, the exhausting air from behind the opposite diaphragm is directed through the air valve assembly(s) to an exhaust port .

As inner chamber pressure **(P1)** exceeds liquid chamber pressure **(P2)**, the rod connected diaphragms shift together creating discharge on one side and suction on the opposite side. The discharged and primed liquid's directions are controlled by the check valves (ball or flap) orientation.

The pump primes as a result of the suction stroke. The suction stroke lowers the chamber pressure (P3) increasing the chamber volume. This results in a pressure differential necessary for atmospheric pressure (P4) to push the fluid through the suction piping and across the suction side check valve and into the outer fluid chamber .

Suction (side) stroking also initiates the reciprocating (shifting, stroking or cycling) action of the pump. The suction diaphragm's movement is mechanically pulled through its stroke. The diaphragm's inner plate makes contact with an actuator plunger aligned to shift the pilot signaling valve. Once actuated, the pilot valve sends a pressure signal to the opposite end of the main directional air valve, redirecting the compressed air to the opposite inner chamber.

#### SUBMERGED ILLUSTRATION



Pump can be submerged if the pump materials of construction are compatible with the liquid being pumped. The air exhaust must be piped above the liquid level. When the pumped product source is at a higher level than the pump (flooded suction condition), pipe the exhaust higher than the product source to prevent siphoning spills.



## **Recommended Installation Guide**

#### **Available Accessories:** 1. Surge Suppressor Unregulated Air Supply to Surge 2. Filter/Regulator Suppressor (1) Surge Suppressor Pressure Gauge **Note**: Surge Suppressor and Piping, including air line, Shut-Off Valve must be supported after Pipe Connection (Style Optional) the flexible connections. Discharge Flexible Connector Check Valve Shut Off Drain Po Muffler Valve (Optional Piped Exhaust) Air Inlet Flexible Connector Compound (2) Filter Regulator Gauge Flexible Connection (3) Dryer Suction (4) Lubricator **CAUTION** Shut-Off Valve The air exhaust should Pipe Connection be piped to an area **Drain Port** (Style Optional) for safe disposition of the product being pumped, in the event of a diaphragm failure.

#### Installation And Start-Up

3. Air Dryer 4. Lubricator

Locate the pump as close to the product being pumped as possible. Keep the suction line length and number of fittings to a minimum. Do not reduce the suction line diameter.

#### Air Supply

Connect the pump air inlet to an air supply with sufficient capacity and pressure to achieve desired performance. A pressure regulating valve should be installed to insure air supply pressure does not exceed recommended limits.

#### Air Valve Lubrication

The air distribution system is designed to operate WITHOUT lubrication. This is the standard mode of operation. If lubrication is designed, install an air line lubricator set to deliver one drop of SAE 10 non-detergent oil for every 20 SCFM (9.4 liters/sec.) of air the pump consumes. Consult the Performance Curve to determine air consumption.

#### Air Line Moisture

Water in the compressed air supply may cause icing or freezing of the exhaust air, causing the pump to cycle erratically or stop operating. Water in the air supply can be reduced by using a point-of-use air dryer.

### Air Inlet And Priming


To start the pump, slightly open the air shut-off valve. After the pump primes, the air valve can be opened to increase air flow as desired. If opening the valve increases cycling rate, but does not increase the rate of flow, cavitation has occurred. The valve should be closed slightly to obtain the most efficient air flow to pump flow ratio.


## **Troubleshooting Guide**


Symptom:	Potential Cause(s):	Recommendation(s):
Pump Cycles Once	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Air valve or intermediate gaskets installed incorrectly.	Install gaskets with holes properly aligned.
	Bent or missing actuator plunger.	Remove pilot valve and inspect actuator plungers.
<b>Pump Will Not Operate</b>	Pump is over lubricated.	Set lubricator on lowest possible setting or remove. Units are designed for lube free operation.
/ Cycle	Lack of air (line size, PSI, CFM).	Check the air line size and length, compressor capacity (HP vs. cfm required).
•	Check air distribution system.	Disassemble and inspect main air distribution valve, pilot valve and pilot valve actuators.
	Discharge line is blocked or clogged manifolds.	Check for inadvertently closed discharge line valves. Clean discharge manifolds/piping.
	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Blocked air exhaust muffler.	Remove muffler screen, clean or de-ice, and re-install.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Pump chamber is blocked.	Disassemble and inspect wetted chambers. Remove or flush any obstructions.
Pump Cycles and Will	Cavitation on suction side.	Check suction condition (move pump closer to product).
Not Prime or No Flow	Check valve obstructed. Valve ball(s) not seating properly or sticking.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket. Clean out around valve ball cage and valve seat area. Replace valve ball or valve seat if damaged. Use heavier valve ball material.
	Valve ball(s) missing (pushed into chamber or manifold).	Worn valve ball or valve seat. Worn fingers in valve ball cage (replace part). Check Chemical Resistance Guide for compatibility.
	Valve ball(s)/seat(s) damaged or attacked by product.	Check Chemical Resistance Guide for compatibility.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Suction line is blocked.	Remove or flush obstruction. Check and clear all suction screens or strainers.
	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
Pump Cycles Running	Over lubrication.	Set lubricator on lowest possible setting or remove. Units are designed for lube free operation.
Sluggish/Stalling,	Icing.	Remove muffler screen, de-ice, and re-install. Install a point of use air drier.
Flow Unsatisfactory	Clogged manifolds.	Clean manifolds to allow proper air flow
Tion Giloudoluciory	Deadhead (system pressure meets or exceeds air supply pressure).	Increase the inlet air pressure to the pump. Pump is designed for 1:1 pressure ratio at zero flow. (Does not apply to high pressure 2:1 units).
	Cavitation on suction side.	Check suction (move pump closer to product).
	Lack of air (line size, PSI, CFM).	Check the air line size, length, compressor capacity.
	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Air supply pressure or volume exceeds system hd.	Decrease inlet air (press. and vol.) to the pump. Pump is cavitating the fluid by fast cycling.
	Undersized suction line.	Meet or exceed pump connections.
	Restrictive or undersized air line.	Install a larger air line and connection.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Suction line is blocked.	Remove or flush obstruction. Check and clear all suction screens or strainers.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Check valve obstructed.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Entrained air or vapor lock in chamber(s).	Purge chambers through tapped chamber vent plugs. Purging the chambers of air can be dangerous.
Product Leaking	Diaphragm failure, or diaphragm plates loose.	Replace diaphragms, check for damage and ensure diaphragm plates are tight.
Through Exhaust	Diaphragm stretched around center hole or bolt holes.	Check for excessive inlet pressure or air pressure. Consult Chemical Resistance Chart for compatibility with products, cleaners, temperature limitations and lubrication.
Premature Diaphragm	Cavitation.	Enlarge pipe diameter on suction side of pump.
Failure	Excessive flooded suction pressure.	Move pump closer to product. Raise pump/place pump on top of tank to reduce inlet pressure. Install Back pressure device (Tech bulletin 41r). Add accumulation tank or pulsation dampener.
	Misapplication (chemical/physical incompatibility).	Consult Chemical Resistance Chart for compatibility with products, cleaners, temperature limitations and lubrication.
	Incorrect diaphragm plates or plates on backwards, installed incorrectly or worn.	Check Operating Manual to check for correct part and installation. Ensure outer plates have not been worn to a sharp edge.
Unbalanced Cycling	Excessive suction lift.	For lifts exceeding 20' of liquid, filling the chambers with liquid will prime the pump in most cases.
	Undersized suction line.	Meet or exceed pump connections.
	Pumped fluid in air exhaust muffler.	Disassemble pump chambers. Inspect for diaphragm rupture or loose diaphragm plate assembly.
	Suction side air leakage or air in product.	Visually inspect all suction-side gaskets and pipe connections.
	Check valve obstructed.	Disassemble the wet end of the pump and manually dislodge obstruction in the check valve pocket.
	Check valve and/or seat is worn or needs adjusting.	Inspect check valves and seats for wear and proper setting. Replace if necessary.
	Entrained air or vapor lock in chamber(s).	Purge chambers through tapped chamber vent plugs.

For additional troubleshooting tips contact After Sales Support at service.warrenrupp@idexcorp.com or 419-524-8388









Optional orientation:

To ease assembly of the TPE diaphragms, one of the diaphragms may be reversed.


## **Composite Repair Parts List - Elastomeric and TPE Fitted**


9011	iibo	site Kepali Parts List		ic and in	PE I ILLEU
Item #	Qty.	Air Valve  Description	Assembly Aluminum Part Number	er Stainles	s Steel Part Number
		Air Side Repair Kit (Includes Items 3,5,7,9,14,16,18-22)	476.V029.000		176.V030.000
1	1	Valve Body (includes items 2-11)	031.V003.156		)31.V003.114
2	1	Valve Body	095.V001.156		095.V001.114
3	1	Valve Body Gasket		P24-202	
4	1	Valve Sleeve		755.V005.148	
5	6	O-ring		560.206.360	
<u>6</u> 7	1	Valve Spool Assembly (Includes items 7)		775.V001.000	
8	6	Glyde Ring Assembly Air Valve Screen	P24-210	P34-204F	P34-210
9	2	End Cap Gasket	1 24-210	P24-205	1 34-210
10	2	End Cap	P34-300		SP34-300
11	13	Mounting Screws (8 included on item 1)	tion Assembly	S1001	
tem#	Qty.	Description Description	Aluminum Part Number	er Stainles	s Steel Part Number
12	1	Center Block Assembly (Includes item 13 & 14)	P34-400DC ASY		SP34-400
13	2	Bearing Sleeve		P34-404	
14	2	Main Shaft O-Ring	400 1/000 457	P34-403	100 ) (000 440
15 16	2 2	Air Chamber Air Chamber Gasket	196.V008.157 P79-109		196.V008.110 360.V001.360
17	8	Bolt	P24-110	<del></del>	SP24-110
	<u> </u>	Pilot Repair Kit (Includes Items 18-22)	127110	476.V028.000	Ç. E. I. IV
18	1	Pilot Sleeve Assembly (include item 19)		755.V002.000	
19	6	O-ring_		560.101.358	
20	1 1	Retaining Ring		675.037.080	
21 22	8	Pilot Spool Assembly (Includes item 22) O-ring	<u> </u>	775.V006.000 560.023.358	
23	1	Muffler		530.033.000	
20	·		embly / Elastomers		
tem #	Qty.	Description	Versa-Rug	Part Number	Versa-Dome
24	1	Main Shaft	versa-Ru <u>c</u>	P34-103	versa-Dome
25	2	Diaphragm (See Below Material Chart)	V305x	(	V306xx
26	2	Outer Diaphragm Plate	SV302B, H\	/302B	SVB307, HVB307
27	2	Inner Diaphragm Plate	V302CD		V307B
28	12	Bolt	V302G		N/A
29 30	12	Washer Bumper Washer	V302G	P34-501	N/A
31	2	Back-Up Washer	1	V302E	
32	4	Valve Seat (See Below Material Chart)		V456xx	
33	4	Valve seat O-Ring		S-1 only used with SV45	
34	4	Valve seat O-Ring	SV456TES	5-2 only used with SV45	6 seat
35	4	Valve Ball (See Below Material Chart)	l Assembly	V455xx	
tem #	Qty.	Description	Assembly	Part Number	
		•		Stainless Steel	
36 37	2 36	Water Chamber Bolt	-	SV350FB SV387A	
38	36	Nut		SV387C	
39	36	Washer		SV387B	
	2	Discharge Manifold		SV351FB	
40	1	Discharge Drop in Manifold		518.V002.110	
	1 1	Discharge Drop in Manifold (BSP)		518.V002.110 E	
	1	Suction Manifold Suction Drop in Manifold		SV352FFB 518.V003.110	
41	1	Suction Drop in Manifold (BSP)		518.V003.110 E	
71	1	Suction WD Drop in Manifold	<del> </del>	518.V003.110 W	
	1 1	Suction WD Drop in Manifold (BSP)	518.V003.110 WE		
42	20	Bolt		170.055.115	,
Mat	erial	Elastomer Mate Versa-Rugged Diaphragm P/N	rial Specifications Versa-Dome Diaphragm P/N	"Ball P/N"	Seat P/N
	orene	Versa-Rugged Diaphragm P/N V305N	V306N	V455N	V456N
Nit	rile	V305BN	V306BN	V455BN	V456BN
Fk	KM	V305VT	V306VT	V455VT	V456VT
EP	DM	V305ND	V306ND	V455ND	V456ND
	FE	N/A	N/A	V455TF	V456TF
	prene trel	V305TPEXL V305TPEFG	N/A N/A	V455TPEXL V455TPEFG	V456TPEXL V456TPEFG
	ss Steel	N/A	N/A N/A	N/A	SV456 (see note 1)
J.aniio		13// \	1 11// 1	13//3	1 01 100 (300 11010 1




3: EXP VIEW

## **Composite Repair Parts Drawing - PTFE Fitted**







## **Composite Repair Parts List - PTFE Fitted**

16000 #	Otes	Description.	Air Valve Assembly	Chairless Charl Don't Novel and
Item #	Qty.	Description Air Side Repair Kit (Includes Items	Aluminum Part Number	Stainless Steel Part Number
		3,5,7,9,14,16,18-22)	476.V029.000	476.V030.000
1	1	Valve Body (includes items 2-11)	031.V003.156	031.V003.114
2	1	Valve Body	095.V001.156	095.V001.114
3	1	Valve Body Gasket		4-202
4	1	Valve Sleeve		005.148
5	6	O-ring		206.360
6	1	Valve Spool Assembly (Includes items 7)		001.000
/	6	Glyde Ring Assembly		-204F
8	2	Air Valve Screen End Cap Gasket	P24-210 P34-210 P24-205	
10	2	End Cap Gasket  End Cap	P34-300	SP34-300
11	13	Mounting Screws (8 included on item 1)		1001
''	10		Center Section Assembly	1001
Item #	Qty.	Description	Aluminum Part Number	Stainless Steel Part Number
12	1	Center Block Assembly (Includes item 13)	P34-400DC ASY	SP34-400
13	2	Bearing Sleeve		4-404
14	2	Main Shaft O-Ring		4-403
15	2	Air Chamber	196.V008.157	196.V008.110
16 17	<u>2</u> 8	Air Chamber Gasket Bolt	P79-109 P24-110	360.V001.360 SP24-110
17	0	Pilot Repair Kit (Includes Items 18-22		028 000
18	1	Pilot Sleeve Assembly (include item 19)	476.V028.000 755.V002.000	
19	6	O-ring	560.101.358	
20	1	Retaining Ring	675.0	037.080
21	1	Pilot Spool Assembly (Includes item 22)	775.V	006.000
22	8	O-ring		)23.358
23	1	Muffler	530.0	033.000
		Diapl	nragm Assembly / Elastomers	N. maha v
Item #	Qty.	Diapl Description	Part I	Number PTFF Fusion
	Qty.	Description	Part I PTFE Two Piece	PTFE Fusion
24	1	Description  Main Shaft	PTFE Two Piece P34-103	PTFE Fusion P34-103F
24 25 26		Description	Part I PTFE Two Piece	PTFE Fusion
24 25 26 27	1 2 2 2	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO	<b>PTFE Fusion</b> P34-103F V305F
24 25 26 27 28	1 2 2 2 2	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI	PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29	1 2 2 2 2 2	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P36	<b>PTFE Fusion</b> P34-103F V305F
24 25 26 27 28 29 30	1 2 2 2 2 2 2 2	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P34 V302E	PTFE Fusion P34-103F V305F N/A
24 25 26 27 28 29 30 31	1 2 2 2 2 2 2 2 2 4	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart)	Part I PTFE Two Piece  P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P3- V302E V456TF (	PTFE Fusion P34-103F V305F N/A 4-501 See Note 1)
24 25 26 27 28 29 30 31 32	1 2 2 2 2 2 2 2 2 4 4	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2)	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P34 V302E V456TF ( SV45	PTFE Fusion P34-103F V305F N/A 4-501 J See Note 1) 6TES-1
24 25 26 27 28 29 30 31 32 33	1 2 2 2 2 2 2 2 2 4 4 4	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2)	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P34 V302E V456TF ( SV45 SV45	PTFE Fusion P34-103F V305F N/A 4-501 See Note 1) 6TES-1 6TES-2
24 25 26 27 28 29 30 31 32	1 2 2 2 2 2 2 2 2 4 4	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2)	Part I PTFE Two Piece  P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P34 V302E V456TF ( SV45 SV45 SV45	PTFE Fusion P34-103F V305F N/A 4-501 J See Note 1) 6TES-1
24 25 26 27 28 29 30 31 32 33 34	1 2 2 2 2 2 2 2 2 4 4 4 4	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P3- V302E V456TF ( SV45 SV45 V4 Wet End Assembly Part I	PTFE Fusion P34-103F V305F N/A 4-501 See Note 1) 6TES-1 6TES-2 55TF
24 25 26 27 28 29 30 31 32 33 34	1 2 2 2 2 2 2 2 2 4 4 4 4	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Valve Ball (See Below Material Chart)  Description	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P3- V302E V456TF ( SV45 SV45 V4 Wet End Assembly Part I	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF
24 25 26 27 28 29 30 31 32 33 34 <b>Item #</b>	1 2 2 2 2 2 2 2 4 4 4 4 4	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber	Part I PTFE Two Piece  P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P3- V302E V456TF ( SV45 SV45 V4 Wet End Assembly Part I Stainle	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number 9ss Steel 850FB
24 25 26 27 28 29 30 31 32 33 34 Item #	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold	Part I PTFE Two Piece  P34-103  V305TF-FB  V305TFB  SV302TO, HV302TO  SV302TI  P3-  V302E  V456TF ( SV45  SV45  Wet End Assembly  Part I Stainle SV3	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number Pass Steel P30FB P387A
24 25 26 27 28 29 30 31 32 33 34 <b>Item #</b> 35 36	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut	Part I PTFE Two Piece  P34-103  V305TF-FB  V305TFB  SV302TO, HV302TO  SV302TI  P3-  V302E  V456TF ( SV45  SV5  SV	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number ses Steel 350FB 387A 387C
24 25 26 27 28 29 30 31 32 33 34 Item #	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16	Description  Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer	Part I PTFE Two Piece  P34-103  V305TF-FB  V305TFB  SV302TO, HV302TO  SV302TI  P3-  V302E  V456TF ( SV45  SV45  Wet End Assembly  Part I Stainle  SV3  SV  SV  SV  SV  SV  SV  SV  SV  S	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number ses Steel 350FB 387A 387C 387B
24 25 26 27 28 29 30 31 32 33 34 Item # 35 36 37 38	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Main Shaft Diaphragm Back Up Diaphragm Duter Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer Discharge Manifold	Part I PTFE Two Piece P34-103 V305TF-FB V305TF-FB SV302TO, HV302TO SV302TI P34 V302E V456TF ( SV45 SV45 SV45 SV45 SV45 SV45 SV45 SV45	PTFE Fusion P34-103F V305F N/A  I 4-501 See Note 1) 6TES-1 6TES-2 55TF Number PSS Steel 350FB 387A 387C 387B 351FB
24 25 26 27 28 29 30 31 32 33 34 <b>Item #</b> 35 36 37	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Main Shaft Diaphragm Back Up Diaphragm Duter Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer Discharge Manifold Discharge Drop in Manifold	Part I PTFE Two Piece  P34-103  V305TF-FB  V305TFB  SV302TO, HV302TO  SV302TI  P34  V302E  V456TF ( SV45  SV5  SV	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number 185 Steel 1850FB 387A 387C 387B 351FB 002.110
24 25 26 27 28 29 30 31 32 33 34 Item # 35 36 37 38	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Main Shaft Diaphragm Back Up Diaphragm Duter Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold	Part I PTFE Two Piece P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI P34 V302E V456TF ( SV45 SV45 SV45 SV45 SV45 SV45 SV45 SV45	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number ses Steel 950FB 387A 387C 387B 351FB 002.110
24 25 26 27 28 29 30 31 32 33 34 Item # 35 36 37 38	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Main Shaft Diaphragm Back Up Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold Discharge Drop in Manifold	Part I PTFE Two Piece  P34-103  V305TF-FB  V305TFB  SV302TO, HV302TO  SV302TI  P34  V302E  V456TF ( SV45  SV45  SV45  SV45  SV45  SV45  SV45  SV45  SV5  SV	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number ess Steel 350FB 387A 387C 3887C 3887B 351FB 002.110 002.110 E 52FFB
24 25 26 27 28 29 30 31 32 33 34 Item # 35 36 37 38	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Main Shaft Diaphragm Back Up Diaphragm Duter Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold	Part I PTFE Two Piece  P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI  P34 V302E  V456TF ( SV45 SV45 SV45 SV45 SV45 SV45 SV45 SV45	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number ess Steel 350FB 387A 387C 387B 387B 3851FB 002.110 002.110 E 52FFB 003.110
24 25 26 27 28 29 30 31 32 33 34 Item # 35 36 37 38	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold	Part I PTFE Two Piece  P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI  P34 V302E  V456TF ( SV45 SV45 SV45 SV45 SV45 SV45 SV45 SV45	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number ess Steel 350FB 387A 387C 3887C 3887B 351FB 002.110 002.110 E 52FFB
24 25 26 27 28 29 30 31 32 33 34 Item # 35 36 37 38 39	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Main Shaft Diaphragm Back Up Diaphragm Outer Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction WD Drop in Manifold	Part I PTFE Two Piece  P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI  P34 V302E  V456TF ( SV45 SV45 SV45 SV45 SV45 SV45 SV45 SV45	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number ess Steel 850FB 387A 387C 387B 951FB 002.110 002.110 E 52FFB 003.110 U 03.110 E 03.110 W 03.110 W
24 25 26 27 28 29 30 31 32 33 34 Item # 35 36 37 38	2 2 2 2 2 2 2 4 4 4 4 4 4 2 16 36	Main Shaft Diaphragm Back Up Diaphragm Plate Inner Diaphragm Plate Inner Diaphragm Plate Bumper Washer Back-Up Washer Valve Seat (See Below Material Chart) Valve seat O-Ring (See Note 2) Valve seat O-Ring (See Note 2) Valve Ball (See Below Material Chart)  Description  Water Chamber Bolt Manifold Nut Washer Discharge Manifold Discharge Drop in Manifold Discharge Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold Suction Drop in Manifold	Part I PTFE Two Piece  P34-103 V305TF-FB V305TFB SV302TO, HV302TO SV302TI  P34 V302E  V456TF ( SV45 SV45 SV45 SV45 SV45 SV45 SV45 SV45	PTFE Fusion P34-103F V305F N/A  4-501 See Note 1) 6TES-1 6TES-2 55TF Number ess Steel 350FB 387A 387C 387B 387C 387B 351FB 002.110 002.110 E 52FFB 003.110 E 03.110 E 03.110 E

#### Notes:

- 1.) (4) SV456 valve seats can be used as an alternative to the PTFE seats.
- 2.) These O-Rings are only needed with the stainless steel valve seat  ${\rm SV456}$



## Material Codes - The Last 3 Digits of Part Number

- 000.....Assembly, sub-assembly; and some purchased items
- 010.....Cast Iron
- 015.....Ductile Iron
- 020.....Ferritic Malleable Iron
- 080.....Carbon Steel, AISI B-1112
- 110.....Alloy Type 316 Stainless Steel
- 111 ..... Alloy Type 316 Stainless Steel (Electro Polished)
- 112.....Alloy C
- 113.....Alloy Type 316 Stainless Steel (Hand Polished)
- 114.....303 Stainless Steel
- 115.....302/304 Stainless Steel
- 117.....440-C Stainless Steel (Martensitic)
- 120.....416 Stainless Steel (Wrought Martensitic)
- 148..... Hardcoat Anodized Aluminum
- 150.....6061-T6 Aluminum
- 152.....2024-T4 Aluminum (2023-T351)
- 155.....356-T6 Aluminum
- 156.....356-T6 Aluminum
- 157.....Die Cast Aluminum Alloy #380
- 158.....Aluminum Alloy SR-319
- 162.....Brass, Yellow, Screw Machine Stock
- 165.....Cast Bronze, 85-5-5-5
- 166.....Bronze, SAE 660
- 170.....Bronze, Bearing Type, Oil Impregnated
- 180.....Copper Alloy
- 305.....Carbon Steel, Black Epoxy Coated
- 306.....Carbon Steel, Black PTFE Coated
- 307.....Aluminum, Black Epoxy Coated
- 308.....Stainless Steel, Black PTFE Coated
- 309.....Aluminum, Black PTFE Coated
- 313.....Aluminum, White Epoxy Coated
- 330.....Zinc Plated Steel
- 332.....Aluminum, Electroless Nickel Plated
- 333.....Carbon Steel, Electroless Nickel Plated
- 335.....Galvanized Steel
- 337.....Silver Plated Steel
- 351.....Food Grade Santoprene®
- 353.....Geolast; Color: Black
- 354..... Injection Molded #203-40
- Santoprene® Duro 40D +/-5;
  - Color: RED
- 356.....Hytrel®
- 357.....Injection Molded Polyurethane
- 358.....Urethane Rubber (Some Applications) (Compression Mold)
- 359.....Urethane Rubber
- 360.....Nitrile Rubber Color coded: RED
- 363.....FKM (Fluorocarbon) Color coded: YELLOW

- 364.....EPDM Rubber
  - Color coded: BLUE
- 365.....Neoprene Rubber
- Color coded: GREEN
- 366.....Food Grade Nitrile
- 368.....Food Grade EPDM
- 371.....Philthane (Tuftane)
- 374.....Carboxylated Nitrile
- 375.....Fluorinated Nitrile
- 378.....High Density Polypropylene
- 379.....Conductive Nitrile
- 408.....Cork and Neoprene
- 425.....Compressed Fibre
- 426.....Blue Gard
- 440.....Vegetable Fibre
- 500.....Delrin® 500
- 502.....Conductive Acetal, ESD-800
- 503.....Conductive Acetal, Glass-Filled
- 506.....Delrin® 150
- 520.....Injection Molded PVDF Natural color
- 540.....Nylon
- 542.....Nylon
- 544.....Nylon Injection Molded
- 550.....Polyethylene
- 551.....Glass Filled Polypropylene
- 552.....Unfilled Polypropylene
- 555.....Polyvinyl Chloride
- 556.....Black Vinyl
- 558.....Conductive HDPE
- 570.....Rulon II®
- 580.....Ryton®
- 600.....PTFE (virgin material) Tetrafluorocarbon (TFE)
- 603.....Blue Gylon®
- 604.....PTFE
- 606.....PTFE
- 607.....Envelon
- 608.....Conductive PTFE
- 610.....PTFE Encapsulated Silicon
- 611.....PTFE Encapsulated FKM
- 632.....Neoprene/Hytrel®
- 633.....FKM/PTFE 634.....EPDM/PTFE
- 635.....Neoprene/PTFE
- 637.....PTFE, FKM/PTFE
- 638.....PTFE, Hytrel®/PTFE
- 639.....Nitrile/TFE
- 643.....Santoprene®/EPDM
- 644.....Santoprene®/PTFE
- 656.....Santoprene® Diaphragm and Check Balls/EPDM Seats
- 661.....EPDM/Santoprene®
- 666.....FDA Nitrile Diaphragm,
  - PTFE Overlay, Balls, and Seals
- 668.....PTFE, FDA Santoprene®/PTFE

- · Delrin and Hytrel are registered tradenames of E.I. DuPont.
- Nylatron is a registered tradename of Polymer Corp.
- Gylon is a registered tradename of Garlock. Inc.
- · Santoprene is a registered tradename of Exxon Mobil Corp.
- Rulon II is a registered tradename of Dixion Industries Corp.
- Ryton is a registered tradename of Phillips Chemical Co.
- · Valox is a registered tradename of General Electric Co.

## RECYCLING

Warren Rupp, manufacturer of Versamatic, is an ISO14001 registered company and is committed to minimizing the impact our products have on the environment. Many components of Versamatic® AODD pumps are made of recyclable materials. We encourage pump users to recycle worn out parts and pumps whenever possible, after any hazardous pumped fluids are thoroughly flushed. Pump users that recycle will gain the satisfaction to know that their discarded part(s) or pump will not end up in a landfill. The recyclability of Versamatic products is a vital part of Warren Rupp's commitment to environmental stewardship.



## 5 - YEAR Limited Product Warranty

#### Quality System ISO9001 Certified • Environmental Management Systems ISO14001 Certified

Versamatic warrants to the original end-use purchaser that no product sold by Versamatic that bears a Versamatic brand shall fail under normal use and service due to a defect in material or workmanship within five years from the date of shipment from Versamatic's factory.

The use of non-OEM replacement parts will void (or negate) agency certifications, including CE, ATEX, CSA, 3A and EC1935 compliance (Food Contact Materials). Warren Rupp, Inc. cannot ensure nor warrant non-OEM parts to meet the stringent requirements of the certifying agencies.

~ See complete warranty at http://vm.salesmrc.com/pdfs/VM\_Product\_Warranty.pdf



Manufacturer: Warren Rupp, Inc. 800 N. Main Street Mansfield, Ohio, 44902 USA

Certifies that Air-Operated Double Diaphragm Pump Models: E Series, VL Series, VM Series, U2 Series; Submersible Pump Models: VSMA3 Series, SPA15 Series and Surge Dampener/Suppressor Models: VDA Series, VTA Series comply with the European Community Directive 2006/42/EC on Machinery, according to Annex VIII. This product has used Harmonized Standard EN809:2012, Pumps and Pump Units for Liquids - Common Safety Requirements, to verify conformance.

October 3, 2022

DATE/APPROVAL/TITLE:

Technical File on record with: DEKRA Certification B.V. Meander 1051 6825 MJ Arnhem The Netherlands Signature of authorized person

Dennis Hall

Printed name of authorized person

**Engineering Manager** 

Title









## **EC Declaration of Conformity**

Manufacturer: Warren Rupp, Inc. 800 N. Main Street Mansfield, Ohio, 44902 USA

Certifies that Air-Operated Double Diaphragm Pump Models: E Series, VL Series, VM Series, U2 Series; Submersible Pump Models: VSMA3 Series, SPA15 Series and Surge Dampener/Suppressor Models: VDA Series, VTA Series comply with the United Kingdom Statutory Instruments 2008 No. 1597, The Supply of Machinery (Safety) Regulations 2008, according to Annex VIII. This product has used Designated Standard EN809:2012, Pumps and Pump Units for Liquids - Common Safety Requirements, to verify conformance.

October 17, 2022

DATE/APPROVAL/TITLE:

Technical File on record with:
DEKRA Certification UK Limited
Stokenchurch House
Oxford Road
Stokenchurch
HP14 3SX

Signature of authorized person

Dennis Hall

Printed name of authorized person

**Engineering Manager** 

Title









## ATEX



## **EU Declaration of Conformity**

### Manufacturer:

Warren Rupp, Inc. A Unit of IDEX Corporation 800 North Main Street Mansfield, OH 44902 USA

This declaration of conformity is issued under the sole responsibility of the manufacturer. Warren Rupp, Inc. declares that Air Operated Double Diaphragm Pumps (AODD) and Surge Suppressors listed below comply with the requirements of Directive **2014/34/EU** and applicable harmonized standards.

Harmonized Standards:

EN ISO 80079-36: 2016
 EN ISO 80079-37: 2016

1. AODD Pumps and Surge Suppressors - Technical File on record with:

DEKRA Certification B.V.

Meander 1051 6825 MJ Arnhem The Netherlands

**Hazardous Location Applied:** 

 $\langle Ex \rangle$ 

II 2 G Ex h IIC T5...225°C (T2) Gb
II 2 D Ex h IIIC T100°C...T200°C Db

- Metal pump models with external aluminum components (E-series, VL Series, VMD Series)
- Versa-Surge® surge suppressors (VTA-Series)

I M2 Ex h Mb



II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- Metal pump models with no external aluminum (E-Series)
- Conductive plastic pumps (E-Series, VMV Series Plastic)

II 2 G Ex h IIB T5...225°C (T2) Gb
II 2 D Ex h IIIB T100°C...T200°C Db

- E1 HP & E2 HP Series due to the projected area of non-conductive external air hoses
- 2. AODD Pumps EU Type Examination Certificate No.: DEKRA 18ATEX0094X DEKRA Certification B.V. (0344)

**Hazardous Location Applied:** 

Meander 1051 6825 MJ Arnhem

The Netherlands

IM1 Ex h I Ma

 $\langle \epsilon_{\rm x} \rangle$ 

II 1 G Ex h IIC T5...225°C (T2) Ga II 1 D Ex h IIIC T100°C...T200°C Da

- Conductive plastic pumps equipped with conductive muffler (VMV Series)
- See "Safety Information" page for conditions of safe use

DATE/APPROVAL/TITLE:

9 NOV 2023

Dennis Hall

**Engineering Manager** 



## **UKEx**



## **EU Declaration of Conformity**

### Manufacturer:

Warren Rupp, Inc.
A Unit of IDEX Corporation
800 North Main Street
Mansfield, OH 44902 USA

This declaration of conformity is issued under the sole responsibility of the manufacturer.

Warren Rupp, Inc declares that Air Operated Double Diaphragm Pumps (AODD) and Surge Suppressors listed below comply with the requirements of United Kingdom Statutory Instruments **2016 No. 1107** and all the applicable standards.

Designated Standards:

EN ISO 80079-36: 2016
 EN ISO 80079-37: 2016

1. AODD Pumps and Surge Suppressors - Technical File on record with: DEKRA Certification UK Limited

Stokenchurch House

Hazardous Location Applied:

Oxford Road Stokenchurch HP14 3SX

 $\langle Ex \rangle$ 

II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- Metal pump models with external aluminum components (E-series, VL Series, VMD Series)
- Versa-Surge<sup>®</sup> surge suppressors (VTA-Series)



I M2 Ex h Mb

II 2 G Ex h IIC T5...225°C (T2) Gb II 2 D Ex h IIIC T100°C...T200°C Db

- · Metal pump models with no external aluminum (E-Series)
- Conductive plastic pumps (E-Series, VMV Series Plastic)



II 2 G Ex h IIB T5...225°C (T2) Gb

II 2 D Ex h IIIB T100°C...T200°C Db

• E1 HP & E2 HP Series due to the projected area of non-conductive external air hoses

See "Safety Information" page for conditions of safe use

DATE/APPROVAL/TITLE: 9 NOV 2023

Dennis Hall

**Engineering Manager**